

BASE

Notes:

1. Make one from 1/2" plywood.
2. Install 1/4-20 threaded inserts or T-nuts at locations A and B. If using T-nuts, install them on the reverse side and counterbore around them so that they sit flush with the surface.
3. Drill hole at C and cut slot at D to clear a 1/4-20 bolt.

